



### **Assembly instruction for SBS1, SBS2 & SBS3 - 2-tier 1/2 round steps**

#### **Step 1. Bottom tread**

Place the bottom sections side by side on a flat, non-scratching surface – the straight sides will align and match. Using 2.5" screws, attach at middle member in the pre-drilled holes.

#### **Step 2. Top tread**

Place the top tread on top of the lower tread and attach to lower unit with 2.5" screws through the pre-drilled holes.